

Product Guide and Manual

G017KX - Cheetah Rotating LED Crystal Ball



This guide/manual forms part of the product and should be kept with the product for future reference.

Product

Rotating LED Crystal Ball. Powered via 3 x AA batteries (not included)

Caution

- For indoor use only
- This is not a toy
- There are no user serviceable parts in this product
- Clean with a slightly damp cloth
- Make sure the product is secure before use
- Take care if adjusting the product when in use

Using the Product

1. Remove the screw from the battery cover on the base of the item
2. Fit 3 new AA batteries into the unit (not supplied). The battery polarities are shown inside the compartment and should be noted when fitting or replacing batteries
3. Replace the battery covers and the screw
4. Place unit on a flat surface and switch on
5. Do not mix new and used batteries

Electrovision Ltd

Lancots Lane, Sutton Oak, St. Helens WA9 3EX

Tel: 01744 745 000 | Fax: 01744 745 002

E-mail: sales@electrovision.co.uk | Web: www.electrovision.co.uk